



LEVEL LOAD AIR SUSPENSION APPLICATION GUIDE

DODGE

YEAR	MODEL	DRIVE TRAIN	DRILL?	FRAME MOUNT	KIT #
1969-1993	D-150, W-100, W-150 (HEAVY LOADS)	2WD/4WD	Y	OUTSIDE	LL-10019 †
1969-1993	D-150, W-100, W-150	2WD/4WD	Y	OUTSIDE	LL-10033 *
1969-1993	D-250, W-250	2WD/4WD	Y	OUTSIDE	LL-10019 †
1969-1993	D-350, W-350	2WD/4WD	Y	OUTSIDE	LL-10019 †
1974-1993	RAM CHARGER	2WD/4WD	Y	OUTSIDE	LL-10033 *
1987-2004	DAKOTA	4WD	Y	OUTSIDE	LL-10033 *
1994-2001	RAM 1500	2WD/4WD	Y	OUTSIDE	LL-10033 *
1994-2001	RAM 1500 (HEAVY LOADS)	2WD	Y	OUTSIDE	LL-10019 †
1994-2002	RAM 2500, RAM 3500	2WD/4WD	Y	OUTSIDE	LL-10019 †
2000-2001	DAKOTA RT	2WD	Y	OUTSIDE	LL-10033 *
2002-2008	RAM 1500 (HEAVY LOADS)	2WD/4WD	N	INSIDE	LL-10071
2003-2013	RAM 2500	4WD	N	INSIDE	LL-10002 ‡
2003-2015	RAM 3500	4WD	N	INSIDE	LL-10002 ‡
2003-2013	RAM 2500	2WD	N	INSIDE	LL-10089 ‡‡
2003-2015	RAM 3500	2WD	N	INSIDE	LL-10089 ‡‡
2006-2008	RAM MEGA CAB (1500, 2500, 3500 MODELS)	4WD	N	INSIDE	LL-10002 ‡
2006-2008	RAM MEGA CAB (1500, 2500, 3500 MODELS)	2WD	N	INSIDE	LL-10089 ‡‡
2007-2011	RAM 4500, RAM 5500 (CHASSIS CAB)	2WD/4WD	N	INSIDE	LL-10121
2007-2009	SPRINTER, 2500	2WD	Y	INSIDE	LL-10147
2009-2015	RAM 1500 (INNER COIL AIR SPRING)	2WD/4WD	N	N/A	LL-10188
2007-2015	RAM 3500 (CHASSIS CAB)	2WD/4WD	N	INSIDE	LL-10002 ‡ + LL-10136

The LL-10136 must be purchased for vehicles that have a round axle tube with the breather located approximately 7" from the spring pack.

FORD

YEAR	MODEL	DRIVE TRAIN	DRILL?	FRAME MOUNT	KIT #
1966-1996	F-100, F-150 (HEAVY LOADS)	4WD	Y	OUTSIDE	LL-10019 †
1966-1996	F-100, F-150 (LIGHT LOADS)	4WD	Y	OUTSIDE	LL-10033 *
1968-1996	F-100, F-150 (HEAVY LOADS)	2WD	Y	OUTSIDE	LL-10019 †
1968-1996	F-100, F-150 (LIGHT LOADS)	2WD	Y	OUTSIDE	LL-10033 *
1969-1979	F-250 (UNDER 7500 GVWR)	2WD	Y	OUTSIDE	LL-10019 †
1970-1997	F-350	2WD	Y	OUTSIDE	LL-10019 †
1980-1996	BRONCO	4WD	Y	OUTSIDE	LL-10033 *
1980-1996	F-250	2WD	Y	OUTSIDE	LL-10019 †
1980-1997	F-250 ('97 HEAVY DUTY OVER 8600 GVWR)	4WD	Y	OUTSIDE	LL-10019 †
1980-1997	F-350 (EXCEPT SUPER HD CHASSIS)	4WD	Y	OUTSIDE	LL-10019 †
1983-1990	BRONCO II	4WD	Y	OUTSIDE	LL-10033 *
1997-1998	F-250 LIGHT DUTY (UNDER 7500 GVWR)	2WD/4WD	Y	OUTSIDE	LL-10019 †
1997-2003	F-150 (INCLUDING HERITAGE)	2WD/4WD	Y	OUTSIDE	LL-10033 *
1999-2004	F-350 SUPER DUTY (11,200 GVWR & UNDER)	2WD	Y	OUTSIDE	LL-10019 †
1998-2010	RANGER **	2WD/4WD	Y	OUTSIDE	LL-10019 †

* THE LL-10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME

** WILL ONLY FIT WITH STOCK WHEELS AND TIRES

‡ THE LL-10002 KITS FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 4WD VEHICLES

‡‡ THE LL-10089 KITS WILL NOT FIT WITH THE 3349 & 3319 SUPERGLIDE 5th WHEEL RAIL KITS ON 2WD VEHICLES

† LL-10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)



LEVEL LOAD AIR SUSPENSION APPLICATION GUIDE

FORD

YEAR	MODEL	DRIVE TRAIN	DRILL?	FRAME MOUNT	KIT #
1999-2010	F-250, F-350 SUPER DUTY	2WD/4WD	Y	OUTSIDE	LL-10070 ††
2010-2015	F-250, F-350 SUPER DUTY <i>Will not fit vehicles with factory installed 5th wheel hitch</i>	2WD/4WD	Y	OUTSIDE	LL-10070 ††
2005-2010	F-250, F-350 SUPER DUTY	2WD	N•	INSIDE	LL-10182 †††
2005-2010	F-250, F-350 SUPER DUTY	4WD	N•	INSIDE	LL-10181 †††
2011-2013	F-250, F-350, F-450 SUPER DUTY	2WD	N•	INSIDE	LL-10169 †††
2014-2015	F-250, F-350 SUPER DUTY	2WD	N•	INSIDE	LL-10194 †††
2011-2013	F-250, F-350, F-450 SUPER DUTY	4WD	N•	INSIDE	LL-10168 †††
2014-2015	F-250, F-350 SUPER DUTY	4WD	N•	INSIDE	LL-10193 †††
2008-2010	F-450 SUPER DUTY (INC. 5TH WHEEL HITCH)	2WD/4WD	N	INSIDE	LL-10187
2015	F-450 SUPER DUTY (INC. 5TH WHEEL HITCH)	2WD/4WD	N	INSIDE	LL-10195
2004-2008	F-150 (HEAVY LOADS) (WILL NOT FIT FX2)	2WD/4WD	N	OUTSIDE	LL-10004
2004-2009	F-150 (EXCLUDES HERITAGE)	2WD/4WD	N	OUTSIDE	LL-10153
2010-2015	F-150 (EXCLUDES HERITAGE & F-150 RAPTOR) <i>Will not fit newer style, aluminum body trucks</i>	2WD/4WD	N	OUTSIDE	LL-10155

GMC/CHEVROLET

YEAR	MODEL	DRIVE TRAIN	DRILL?	FRAME MOUNT	KIT #
1968-1987	C-3500	2WD	Y	OUTSIDE	LL-10019 †
1969-1991	JIMMY/BLAZER	4WD	Y	OUTSIDE	LL-10033 *
1973-1991	JIMMY/BLAZER	2WD	Y	OUTSIDE	LL-10033 *
1973-1987	C-1500, C-2500, C-10, C-20, C-30	2WD	Y	OUTSIDE	LL-10019 †
1973-1987	K-10 & K-1500	4WD	Y	OUTSIDE	LL-10033 *
1988-1998	C-1500, K-1500	2WD/4WD	Y	OUTSIDE	LL-10033 *
1988-1998	SIERRA/SILVERADO 1500 ^Δ	2WD/4WD	Y	INSIDE	} LL-10088 ***
1988-1998	SIERRA/SILVERADO 2500 ^Δ	2WD/4WD	Y	INSIDE	
1999-2000	SIERRA/SILVERADO 2500 (DRUM BRAKES ONLY) ^Δ	2WD/4WD	Y	INSIDE	
1988-2000	SIERRA/SILVERADO 3500 ^Δ	2WD/4WD	Y	INSIDE	LL-10120 ***
1999-2004	SIERRA/SILVERADO 2500	2WD/4WD	N	INSIDE	LL-10072 ****
1999-2007	SIERRA/SILVERADO 1500	2WD/4WD	Y	OUTSIDE	LL-10033 *
2001-2006	SIERRA/SILVERADO 1500HD (HEAVY LOADS)	2WD/4WD	N	INSIDE	LL-10072 ****
2001-2010	SIERRA/SILVERADO 2500HD, 3500 <i>Not for commercial cab and chassis</i>	2WD/4WD	N	INSIDE	LL-10005
2001-2005	SILVERADO 1500HD	2WD/4WD	Y	OUTSIDE	LL-10033 *
2001-2008	SIERRA 1500HD	2WD/4WD	Y	OUTSIDE	LL-10033 *
2007-2015	SIERRA/SILVERADO 1500 <i>(68.4" & 78" truck bed applications)</i>	2WD/4WD	N	OUTSIDE	LL-10144
2007-2015	SIERRA/SILVERADO 1500 <i>(for 8ft bed)</i> <i>(97.8" truck bed applications)</i>	2WD/4WD	N	OUTSIDE	LL-10178
2011-2015	SIERRA/SILVERADO 2500/3500 <i>Not for commercial cab and chassis</i>	2WD/4WD	N•	INSIDE	LL-10171 †††

* THE LL-10033 KIT REQUIRES 6" BETWEEN THE TIRE AND FRAME

*** FOR 'C' CHANNEL FRAMES

**** FOR HYDRO FORMED FRAMES

† LL-10019 KITS FIT WITH A REESE 5th WHEEL RAIL KIT (MODELS 30033, 30035 & 30729)

†† LL-10070 KITS FIT WITH A DRAW TITE 15000 5th WHEEL HITCH

††† FOR ALL TRUCKS, INCLUDING THOSE WITH 5th WHEEL HITCHES. NOT FOR CHASSIS CAB TRUCKS.

Δ IF THE FRAME TO AXLE PAD DISTANCE IS 7.25" OR LESS, USE KIT LL-10120

• DRILLING MAY BE REQUIRED ON TRUCKS WITH AN AFTERMARKET 5th WHEEL HITCH



LEVEL LOAD AIR SUSPENSION APPLICATION GUIDE

FREIGHTLINER

YEAR	MODEL	DRIVE TRAIN	DRILL?	FRAME MOUNT	KIT #
2007-2014	SPRINTER, 2500	2WD	Y	INSIDE	LL-10147

MAZDA

YEAR	MODEL	DRIVE TRAIN	DRILL?	FRAME MOUNT	KIT #
1998-2010	MAZDA PICK-UPS <i>Will only fit with stock wheels and tires</i>	2WD/4WD	Y	OUTSIDE	LL-10019 †

MERCEDES

YEAR	MODEL	DRIVE TRAIN	DRILL?	FRAME MOUNT	KIT #
2010-2014	SPRINTER, 2500	2WD	Y	INSIDE	LL-10147

STERLING

YEAR	MODEL	DRIVE TRAIN	DRILL?	FRAME MOUNT	KIT #
2007-2011	BULLET 4500, BULLET 5500 (CHASSIS CAB)	2WD/4WD	N	INSIDE	LL-10121

TOYOTA

YEAR	MODEL	DRIVE TRAIN	DRILL?	FRAME MOUNT	KIT #
ALL TOYOTA KITS REQUIRE A MINIMUM OF 5" BETWEEN THE TIRE AND FRAME AND WILL ONLY FIT WITH STOCK WHEELS AND TIRES					
1995-2004	TOYOTA TACOMA	4WD	N	OUTSIDE	LL-10191
2001-2006	TOYOTA TUNDRA	2WD/4WD	N	OUTSIDE	LL-10126
2001-2006	TOYOTA TUNDRA <i>Trucks in which the upper jounce bumper pad protrudes 1" below the frame</i>	2WD/4WD	N	OUTSIDE	LL-10158
2007-2015	TOYOTA TUNDRA	2WD/4WD	N	OUTSIDE	LL-10128
2005-2015	TOYOTA TACOMA	4WD	N	OUTSIDE	LL-10165

UNIVERSAL FIT

MODEL	KIT #
FABRICATORS REAR AIR SPRING KIT (SMALL AIR SPRINGS)	LL-10130
FABRICATORS FRONT AIR SPRING KIT (LARGE AIR SPRINGS)	LL-10086



AIR SUSPENSION SPACERS (for lifted trucks)

2" - LL-10152

4" - LL-10154

6" - LL-10156

LEVEL LOAD AIR SUSPENSION REPLACEMENT AIR SPRINGS

LL-10000, *DOUBLE CONVOLUTED AIR SPRING*

USED IN KITS: LL-10002, LL-10004, LL-10005, LL-10019, LL-10070, LL-10071, LL-10072, LL-10088, LL-10130, LL-10147, LL-10168, LL-10169, LL-10171, LL-10181, LL-10182, LL-10187, LL-10195

LL-10068, *LARGE DOUBLE CONVOLUTED AIR SPRING*

USED IN KITS: LL-10086, LL-10121

LL-10083, *SINGLE CONVOLUTED AIR SPRING*

USED IN KITS: LL-10089, LL-10120, LL-10126, LL-10128, LL-10158

LL-10001, *SLEEVE-STYLE AIR SPRING*

USED IN KITS: LL-10033, LL-10144, LL-10155, LL-10165, LL-10178

LL-10173, *SLEEVE-STYLE AIR SPRING*

USED IN KITS: LL-10153, LL-10191

LL-10189, *INNER-COIL AIR SPRING*

USED IN KIT: LL-10188